



Electronic Timer Stopwatch
Item #7653

INSERT BATTERY BEFORE USING

1. Slide battery cover on backside of timer case in direction of arrow.
2. Insert 1 AAA battery into opening, matching plus(+) and minus symbols.
3. Slide cover down over battery, making sure it locks into place.
Your timer is now ready to use.

SET TIME

1. Press RESET to clear display.
2. Enter 4 digits - minutes, seconds in that order, pressing 0 anytime a number is not required. Example: 2 minutes, 30 seconds = 02 30

TO OPERATE

1. Press START button to start timing. If the wrong time has been set, simply press the START/STOP button to stop timing. Press RESET to reset time to zero.
2. Electronic tone announces when time is up.
3. To start stopwatch press START button once. Stopwatch will immediately begin to count up in seconds. To stop count-up, press START/STOP button.



Patterson Medical
1000 Remington Blvd.
Suite 210
Bolingbrook, IL 60440
Phone: 800-323-5547
Direct Phone: 630-378-6000
Fax: 800-547-4333
Direct Fax: 630-378-6310